

Beverage Fountain Instructions

***Beverage Fountains are designed to circulate clear beverages. Use of beverages with pulp, seeds, fruit, rinds, etc. will restrict the flow of the beverage. Ice cream, foamy punches or pre-mixed punches may not be used in the fountain. ***

Operating Instructions:

- Pour approximately two quarts of beverage in lower reservoir and turn switch on.
- If beverage does not circulate within one minute, turn switch off for 10 seconds, then turn back on.
- You may need to repeat this procedure several times until the beverage starts to flow freely.
- Add more of the beverage as needed.

Important: Do not run fountain dry. Do not immerse base of fountain in water.

Cleaning Instructions:

After use, empty out remaining beverage and fill lower reservoir with two gallons of warm water and let circulate for five (5) minutes. Empty the unit and repeat.

DO NOT use scouring pads or any type of abrasive material or cleaning product.

DO NOT TAKE UNIT APART!!!

Helpful Hints:

- To chill a beverage, use chunks of ice in the bowl, ice cubes in a plastic bag, or several pieces of dry ice in the bowl.
- Pre-cool your beverage whenever possible to at least 36°F before adding to fountain.
- When using carbonated beverages, pre-chill to at least 36°F before adding to fountain. To avoid dilution, place bags of ice enclosed in plastic in the fountain bowl. Carbonation will dissipate after 10-20 minutes of recirculation in the fountain. It is advisable to add smaller quantities of carbonated mixtures to the fountain from time to time to maintain carbonation.